
































MONTAGEANLEITUNG
INSTRUCTIONS DE MONTAGE
ASSEMBLY INSTRUCTIONS
MONTAGEAANWIJZING




102	8		
111	2		
120	2		
190	8		Ø8 x 30 mm
191	28		Ø5 x 30 mm
193	16		Ø5 x 40 mm
220	6		
246	1		
247	1		
250	18		
320	8		6 x 50 mm
351	2		3,5 x 15 mm
359	18		3 x 25 mm
370	1		4 x 15 mm
371	1		6 x 60 mm
741	1		Ø8 x 51 mm
742	1		








1x






1x






























6x

220





8x

