



Assembly Instructions

A		1PC
B		1PC
C		1PC
D		4PCS
E		1PC
F		1PC
G		1PC
H		1PC
I	 M8*50MM	1PC
J	 M8*20mm	4PCS
K	 M6*45mm	7 PCS
L	 M6*40mm	2 PCS
M	 M8	1PC
N	 M6	1PC
O	 M6	1PC
P	 M4	1PC
Q		1PC


Setp 1




Setp 2




Setp 3




Setp 4



Setp 5



Setp 6



IMPORTANT & WARNINGS:

- Remove all parts from packaging carefully.
- This is a heavy unit!! When assembling and unassembling we recommend that 2 or more adults are involved.
- Keep children & Pets away when assembling or unassembling.
- Do not climb on the frame
- This product is not a toy and should NOT be used as a swing under any circumstances as this could result in injury.
- Max recommended weight is 120Kgs
- This product is only designed to seat 1 person at any given time. DO NOT exceed this as this could damage the product and cause injury; and void your warranty.
- Keep all flame and heat sources well away from this product at all times.
- Take care not to trap fingers whilst assembling and unassembling.
- When not in use please store away in a cool and dry place away from any heat source.