


ASSEMBLY INSTRUCTION

FIGO DC67



A×1



B×1



C×1




D×4



6×30MM

E×4



6×18MM

F×1



6×20MM

G×1



5MM

ASSEMBLY INSTRUCTION
FIG. 1007

