

DC-B8092 CRUX ASSEMBLY INSTRUCTON



① ×1



② ×1



φ 6X φ 16

③ ×4



M6×16

④ ×4



4#

⑤ ×1

