



ASSEMBLING INSTRUCTION

ITEM: GT-41028-AAA

COMPONENT PARTS LIST




A*1




B*4

ASSEMBLY INSTRUCTION

Stage1



Stage2



HARDWARE LIST

NO.	DESCRIPTIONS	Q. ty
C	 M8*35	8
D	 M8	8
E	 M8	8
F	 M8	1