

ASSEMBLY INSTRUCTIONS

MODEL : FP118 CT

Thank you for purchasing this quality product. Be sure to lay all components on a soft and clean surface before assembly in order to avoid components from being scratched.


CAUTIONS :

1. Check contents against hardware list.
2. Familiarize yourself with the components and hardware by reviewing the Assembly Instructions.
3. Do not over tighten the screws and bolts as it may damage the threads.
4. Keep all hardware parts out of reach of children.
5. Please "LIFT UP & MOVE" the sofa whenever you want to shift it.

PART LIST		
NO.	DESCRIPTION	QTY
1	TABLE TOP 	1 pc
2	TABLE LEG 	4 pcs

HARDWARE LIST		
NO.	DESCRIPTION	QTY
A	JCBC M6 x 60mm 	8 pcs
B	FLAT WASHER 	8 pcs
C	SPRING WASHER 	8 pcs
D	ALLEN KEY M4 	1 pc

STEP 1



FINISH ASSEMBLY