


ASSEMBLY INSTRUCTION


MODEL: 1234 - TV CABINET

HARDWARE	A	B	C	D	E	F	G	H	I	J	K	L	
	PLASTIC DOWEL 8 X 25	CB SCREW M3.5X16MM	CB SCREW M4.5X45MM	CSK CAP M6X40MM	POWER NAIL 6/8	ALLEN KEY	MINIFIX CAP	PVC SHELF SUPPORT	PLASTIC PIN	J1 HINGES 2/8	K1 K2 MINIFIX 5654	L1 VSC 12 (PVC)	L2 P/H SCREW 4X 20MM
	1X30	1X16	1X4	1X12	1X38	1X1	1X16	1X4	1X8	4 sets	1X8	1X2	1X4


PART LIST




STEP 1




STEP 2




STEP 3




STEP 4




STEP 5




STEP 6




STEP 7




STEP 8



STEP 9







ASSEMBLY INSTRUCTION

MODEL: 1234 - TV CABINET


STEP 10




STEP 11




STEP 12



STEP 13



STEP 14



COMPLETED ASSEMBLY

